

 Phone:
 203-647-9147

 Fax:
 203-200-7886

 Email:
 sales@haywardts.com


 Mail:
 160 Wampus Lane

 Milford, CT 06460

HT431 Full Height Turnstile

Complete Dimensions and Mounting Information





All measurements are referenced from the center of the rotating arm assembly.

A total of 8 holes need to be drilled in the floor to mount the turnstile (3 for the fixed arm assembly, 1 for the rotating arm bearing & 4 for the cage assembly).

Hint: you can lay the top channel on the ground where you want the turnstile (be sure the orientation is correct). Use a magic marker to trace 6 of the 8 hole locations. The last 2 can either be measured or each cage can be used as a template.

> Overall Length 62 $\frac{3}{8}$ " Overall Width 55" Overall Height 89 $\frac{3}{8}$ "

